
MOOG Nideolarm

© 2009, Videolarm, Inc. All Rights Reserved



FDW8CF2

Fusion Dome (Outdoor/Indoor Housing with Wall Mount)

www.videolarm.com

Installation and Operation Instructions for the following models:

FDW8CF2 8" Outdoor dome hsg w/wall mount, clear dome, w/24Vac input,

heater/ blower, (1) fixed camera bracket, MCL8.5"

FDP8CF2 8" Outdoor dome hsg w/pendant mount, clear dome, w/24Vac input,

heater/ blower, (1) fixed camera bracket, MCL8.5"

FDP8CF2 8" Indoor dome hsg w/wall mount, tinted dome, plus (1) fixed camera

bracket, MCL8.5"

IFDP8CF 8" Indoor dome hsg w/pendant mount, tinted dome, plus (1) fixed camera

bracket, MCL8.5"

ISOCERTIFIED

81-IN5417
01-29-2009

Before attempting to connect or operate this product, please read these instructions completely.

IMPORTANT SAFEGUARDS

- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Heed all warnings
- 4 Follow all instructions.
- 5 Do not use this apparatus near water.
- 6 Clean only with damp cloth.
- 7 Do not block any of the ventilation openings. Install in accordance with the manufacturers instructions.
- 8 Cable Runs- All cable runs must be within permissible distance.
- 9 Mounting This unit must be properly and securely mounted to a supporting structure capable of sustaining the weight of the unit.

Accordingly:

- a. The installation should be made by a qualified installer.
- **b.** The installation should be in compliance with local codes.
- c. Care should be exercised to select suitable hardware to install the unit, taking into account both the composition of the mounting surface and the weight of the unit.
- 10 Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 11 Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 12 Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 13 Only use attachment/ accessories specified by the manufacturer.
- 14 Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 15 Unplug this apparatus during lighting storms or when unused for long periods of time.
- 16 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled of objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Be sure to periodically examine the unit and the supporting structure to make sure that the integrity of the installation is intact. Failure to comply with the foregoing could result in the unit separating from the support structure and falling, with resultant damages or injury to anyone or anything struck by the falling unit.

UNPACKING

Unpack carefully. Electronic components can be damaged if improperly handled or dropped. If an item appears to have been damaged in shipment, replace it properly in its carton and notify the shipper.

Be sure to save:

- 1 The shipping carton and packaging material. They are the safest material in which to make future shipments of the equipment.
- 2 These Installation and Operating Instructions.

SERVICE

If technical support or service is needed, contact us at the following number:

TECHNICAL SUPPORT AVAILABLE 24 HOURS 1-800-554-1124

SAFETY PRECAUTIONS



CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER- SERVICE-ABLE PARTS INSIDE. REFER SEVICING TO QUALIFIED SERVICE PERSONNEL.



The lightning flash with an arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of non-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk to persons.

Este símbolo se piensa para alertar al usuario a la presencia del "voltaje peligroso no-aislado" dentro del recinto de los productos que puede ser un riesgo de choque eléctrico.

Ce symbole est prévu pour alerter l'utilisateur à la presence "de la tension dangereuse" non-isolée dans la clôture de produits qui peut être un risque de choc électrique.

Dieses Symbol soll den Benutzer zum Vorhandensein der nicht-Isolier "Gefährdungsspannung" innerhalb der Produkteinschließung alarmieren die eine Gefahr des elektrischen Schlages sein kann.

Este símbolo é pretendido alertar o usuário à presença "di tensão perigosa non-isolada" dentro do cerco dos produtos que pode ser um risco de choque elétrico.

Questo simbolo è inteso per avvertire l'utente alla presenza "di tensione pericolosa" non-isolata all'interno della recinzione dei prodotti che può essere un rischio di scossa elettrica.



The exclamation point within an equilateral triangle is intended to alert the user to presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Este símbolo del punto del exclamation se piensa para alertar al usuario a la presencia de instrucciones importantes en la literatura que acompaña la aplicación.

Ce symbole de point d'exclamation est prévu pour alerter l'utilisateur à la presence des instructions importantes dans la littérature accompagnant l'appareil.

Dieses Ausruf Punktsymbol soll den Benutzer zum Vorhandensein de wichtigen Anweisungen in der Literatur alarmieren, die das Gerät begleitet.

Este símbolo do ponto do exclamation é pretendido alertar o usuário à presença de instruções importantes na literatura que acompanha o dispositivo.

Questo simbolo del punto del exclamaton è inteso per avvertire l'utente alla presenza delle istruzioni importanti nella letteratura che accompagna l'apparecchio.



LIMITEDWARRANTY FOR VIDEOLARM INC. PRODUCTS

VIDEOLARMINC. warrantsthis Product to be free from defects in material or workmanship, as follows:

PRODUCTCATEGORY	PARTS	LABOR	
All Enclosures and Electronics	Five (5) Years	Five (5) Years	
Pan/Tilts	Three (3) Years **6 months if used in autoscan	Three (3) Years **6 months if used in autoscan	
Poles/PoleEvators	Three (3) Years /tour operation	Three (3) Years /tour operation	
Warrior/Q-View/I.R. Illuminators	Five (5) Years	Five (5) Years	
SView Series	Five (5) Years **6 months if used in autoscan	Five (5) Years **6 months if used in autoscan	
Controllers	Five (5) Years /tour operation	Five (5) Years /tour operation	
Power Supplies	Five (5) Years	Five (5) Years	
Accessory Brackets	Five (5) Years	Five (5) Years	

During the labor warranty period, to repair the Product, Purchaser will either return the defective product, freight prepaid, or deliver it to Videolarm Inc. Decatur GA. The Product to be repaired is to be returned in either its original carton or a similar package affording an equal degree of protection with a RMA # (Return Materials Authorization number) displayed on the outer box or packing slip. To obtain a RMA# you must contact our Technical Support Team at 800.554.1124, extension 101. Videolarm will return the repaired Product freight prepaid to Purchaser. Videolarm is not obligated to provide Purchaser with a substitute unit during the warranty period or at any time. After the applicable warranty period, Purchaser must pay all labor and/or parts charges.

The limited warranty stated in these product instructions is subject to all of the following terms and conditions: TERMS AND CONDITIONS

- **1.NOTIFICATIONOF CLAIMS: WARRANTY SERVICE:** If Purchaser believes that the Product is defective in material or workmanship, then written notice with an explanation of the claim shall be given promptly by Purchaser to Videolarm but all claims for warranty service must be made within the warranty period. If after investigation Videolarm determines that the reported problem was not covered by the warranty, Purchaser shall pay Videolarm for the cost of investigating the problem at its then prevailing per incident billable rate. No repair or replacement of any Product or part thereof shall extend the warranty period as to the entire Product. The specific warranty on the repaired part only shall be in effect for a period of ninety (90) days following the repair or replacement of that part or the remaining period of the Product parts warranty, whichever is greater.
- 2. EXCLUSIVE REMEDY: ACCEPTANCE: Purchaser's exclusive remedy and Videolarm's sole obligation is to supply (or pay for) all labor necessary to repair any Product found to be defective within the warranty period and to supply, at no extra charge, new or rebuilt replacements for defective parts.

 3. EXCEPTIONS TO LIMITED WARRANTY: Videolarm shall have no liability or obligation to Purchaser with respect to any Product requiring service during the warranty period which is subjected to any of the following: abuse, improper use: negligence, accident, lightning damage or other acts of God (i.e., hurricanes, earthquakes), modification, failure of the end-user to follow the directions outlined in the product instructions, failure of the end-user to follow the maintenance procedures recommended by the International Security Industry Organization, written in product instructions, or recommended in the service manual for the Product. Furthermore, Videolarm shall have no liability where a schedule is specified for regular replacement or maintenance or cleaning of certain parts (based on usage) and the end-user has failed to follow such schedule; attempted repair by non-qualified personnel; operation of the Product outside of the published environmental and electrical parameters, or if such Product's original identification (trademark, serial number) markings have been defaced, altered, or removed. Videolarm excludes from warranty coverage Products sold AS IS and/or WITH ALL FAULTS and excludes used Products which have not been sold by Videolarm to the Purchaser. All software and accompanying documentation furnished with, or as part of the Product is furnished "AS IS" (i.e., without any warranty of any kind), except where expressly provided otherwise in any documentation or license agreement furnished with the Product.
- **4. PROOF OF PURCHASE:** The Purchaser's dated bill of sale must be retained as evidence of the date of purchase and to establish warranty eligibility. **DISCLAIMEROF WARRANTY**

EXCEPT FOR THE FOREGOING WARRANTIES, VIDEOLARM HEREBY DISCLAIMS AND EXCLUDES ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO ANY AND/OR ALL IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND/OR ANY WARRANTY WITH REGARD TO ANY CLAIM OF INFRINGEMENT THAT MAY BE PROVIDED IN SECTION 2-312(3) OF THE UNIFORM COMMERCIAL CODE AND/OR IN ANY OTHER COMPARABLE STATUTE. VIDEOLARM HEREBY DISCLAIMS ANY REPRESENTATIONS OR WARRANTY THAT THE PRODUCT IS COMPATIBLE WITH ANY COMBINATION OF NON-VIDEOLARM PRODUCTS OR NON-VIDEOLARM RECOMMENDED PRODUCTS PURCHASER CHOOSES TO CONNECT TO PRODUCT.

LIMITATION OF LIABILITY

THE LIABILITY OF VIDEOLARM, IF ANY, AND PURCHASER'S SOLE AND EXCLUSIVE REMEDY FOR DAMAGES FOR ANY CLAIM OF ANY KIND WHATSOEVER, REGARDLESS OF THE LEGAL THEORY AND WHETHER ARISING IN TORT OR CONTRACT, SHALL NOT BE GREATER THAN THE ACTUAL PURCHASE PRICE OF THE PRODUCT WITH RESPECT TO WHICH SUCH CLAIM IS MADE. IN NO EVENT SHALL VIDEOLARM BE LIABLE TO PURCHASER FOR ANY SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY KIND INCLUDING, BUT NOT LIMITED TO, COMPENSATION, REIMBURSEMENT OR DAMAGES ON ACCOUNT OF THE LOSS OF PRESENT OR PROSPECTIVE PROFITS OR FOR ANY OTHER REASON WHATSOEVER.



Electrical Specifications

Power 24VAC Class 2 Only

FDW8CF2



24 VAC 26 Watts Accessories: Camera Power: Tools Required:

Heater: 25 Watts, Blower: 1 Watt 32 Watts Max .100" Flat Head Screwdriver Phillips Head Screwdriver

English



26 vatios Calentador: 25 Vatios, Soplador: 1 vatio Accesorios: Energía De la Cámara fotográfica: 32 vatios Max Las Herramientas Requirieron: Destornillador Principal Plano Del 100". Destornillador Principal Phillips.

Español



24 VCA 26 watts

Réchauffeur : 25 Watts, Ventilateur : 1 watt Accessoires: Puissance D'Appareil-photo: 32 watts Max Les Outils Ont exigé: Tournevis Principal Plat De 100". Tournevis Principal Phillips.

Français



24 VAC 26 Watt

Zusatzgeräte: Heizung: 25 Watt, Gebläse: 1 Watt. Kamera-Energie: 32 Watt Max Werkzeuge Erforderten: 100"Flacher Hauptschraubenzieher. Kreuzkopfhauptschraubenzieher.

Deutsch

24 VAC

26 watts Acessórios: Calefator: 25 Watts, Ventilador: 1 watt. Poder Da Câmera: 32 watts Max Chave de fenda Principal Lisa Do Ferramentas Requeridas: 100". Chave de fenda Principal Phillips.

Portuguese



24 VCA. 26 watt

Accessori: Riscaldatore: 25 Watt, Ventilatore: 1 watt. Alimentazione Della Macchina fotografica: 32 watt Max Gli Attrezzi Hanno richiesto: Cacciavite Capo Piano Del 100". Cacciavite Capo "phillips".

Italiano

IFDP8CF **IFDW8CF (INDOOR ONLY)**



Indoor Models IFDP8CF/ IFDW8CF Include NO Power Accessories

International Models IFDW8C2FE/ IFDP8C2FE Include NO **Power Transformer**

24 VAC

No power options provided. Power required for camera only.

Ningunas opciones de la energía proporcionaron. Energía requerida para la cámara fotográfica solamente.


Option de puissance n'a pas fourni. Puissance requise pour l'appareil-photo seulement.

Keine Energie Wahlen stellten zur Verfügung. Energie erfordert für nur Kamera.

Nenhumas opções do poder fornecidas. Poder requerido para a câmera somente.

Nessun'opzione di alimentazione ha fornito. Alimentazione richiesta per la macchina fotografica soltanto.

Contents of Box





Securely mount unit to wall or to appropriate adapter bracket.

- Monte con seguridad la unidad a la pared o al soporte apropiado del adaptador.
- Montez solidement l'unité au mur ou à la parenthèse appropriée d'adapteur.
- Bringen Sie sicher Maßeinheit zur Wand oder zum passenden Adapterhaltewinkel an.
- Monte firmemente a unidade à parede ou ao suporte apropriado do adaptador.
- Monti saldamente l'unità alla parete o alla staffa adatta dell'adattatore.




If using conduit connect, connect to incoming conduit fitting.

- Si usa el conducto conecte, conecte con la guarnición entrante del conducto.
- Si à l'aide du conduit reliez, reliez à l'ajustage de précision entrant de conduit.
- Wenn Sie Rohr verwenden, schließen Sie an, schließen Sie an ankommende Rohrbefestigung an.
- Se usando a canalização conecte, conecte ao encaixe entrante da canalização.
- Se per mezzo del condotto colleghi, colleghi al montaggio ricevuto del condotto.




Open access door to access power and control connectors.

- Abra la puerta de acceso en los conectadores de la energía y de control del acceso.
- Ouvrez la porte d'accès aux connecteurs de puissance et de commande d'accès.
- Öffnen Sie Zugang zur Zugang Energie und zu den Geräteanschlüssen.
- Abra a porta de acesso aos conectores do poder e de controle do acesso.
- Apra il portello di accesso ai connettori di alimentazione e di controllo di accesso.




Make wire connection as they are required for your needs.

- Haga la conexión del alambre como se requieren para sus necesidades.
- Établissez le rapport de fil comme ils sont exigés pour vos besoins.
- Stellen Sie Leitung Beziehung her, wie sie für Ihre Notwendigkeiten angefordert werden.
- Faça a conexão do fio como são requeridos para suas necessidades.
- Faccia il collegamento del legare come sono richiesti per i vostri bisogni.




Securely mount bracket to wall. Pull wiring through bracket and position grommet as shown.

- Con seguridad soporte del montaje a emparedar. Tire del cableado a través del soporte y del ojal de la posición según lo demostrado.
- Solidement parenthèse de bâti à murer. Tirez le câblage par la parenthèse et le canon isolant de position comme montré.
- Sicher Einfassung Haltewinkel wall. Ziehen Sie Verdrahtung durch Haltewinkel und Position Gummimuffe, wie gezeigt.
- Firmemente suporte da montagem a wall. Puxe a fiação através do suporte e do ilhó da posição como mostrado.
- Saldamente staffa del supporto da wall. Tiri i collegamenti tramite la staffa ed il gommino di protezione di posizione come indicato.




Wrap Teflon tape around the pipe threads to ensure a tight seal.

- La cinta del Teflon del abrigo alrededor de la pipa rosca para asegurar un sello apretado.
- La bande de teflon d'enveloppe autour de la pipe filète pour assurer un joint serré.
- Verpackung Teflonklebeband um das Rohr verlegt, um eine feste Dichtung sicherzustellen.
- A fita adesiva do Teflon do envoltório em torno da tubulação enfía para assegurar um selo apertado.
- Il nastro del Teflon dell'involucro intorno al tubo filetta per accertare una guarnizione stretta.




Screw the coupling onto the pipe threads until it is hand tight.

- Atornille el acoplador sobre los hilos de rosca de la pipa hasta que es mano firmemente.
- Vissez le couplage sur les fils de pipe jusqu'à ce que ce soit main fortement.
- Schrauben Sie die Koppelung auf die Rohrgewinde, bis es Hand fest ist.
- Parafuse o acoplamento nas linhas da tubulação até que esteja mão firmemente.
- Avviti l'accoppiamento sui filetti del tubo fino a che non sia fortemente mano.



Screw the (2) bolts into the coupling.


- Atornille (2) los pernos en el acoplador.
- Vissez (2) les boulons dans l'accouplement.
- Schrauben Sie die (2) Schraubbolzen in die Koppelung.
- Parafuse (2) os parafusos no acoplamento.
- Avviti (2) i bulloni nell'accoppiamento.



Loop the lanyard over the set screw to temporarily hold housing.

- Coloque el acollador sobre el tornillo de presión para celebrar temporalmente la cubierta.
- Faites une boucle la lanière au-dessus de la vis de réglage pour tenir temporairement le logement.
- Schlingen Sie die Abzuglinie über der Klemmschraube, um Gehäuse vorübergehend zu halten.
- Dê laços no colhedor sobre o parafuso de fixação para prender temporariamente a carcaça.
- Colleghi la cordicella in circuito sopra la vite di arresto temporaneamente per tenere l'alloggiamento.






Make the appropriate wiring connections from the dome to the gooseneck.

- Haga las conexiones apropiadas del cableado de la bóveda al gooseneck.
- Établissez les rapports appropriés de câblage à partir du dôme au col de cygne.
- Stellen Sie die passenden Verdrahtung Beziehungen von der Haube zum gooseneck her.
- Faça as conexões apropriadas da fiação da abóbada ao gooseneck.
- Faccia i collegamenti adatti dei collegamenti dalla cupola al gooseneck.

11



Undo the lanyard, pull housing up and twist secure with the locking bolt and washers.

- Deshaga el acollador, tire de contener para arriba y tuerza seguro con el perno y las arandelas de fijación.
- Défaites la lanière, tirez loger vers le haut et tordez bloqué avec le boulon et les rondelles de fermeture.
- Annulieren Sie die Abzuglinie, ziehen Sie oben unterbringen und verdrehen Sie sicheres mit dem verriegelnschraubbolzen und den Unterlegscheiben.
- Undo o colhedor, puxe abrigar acima e torça seguro com o parafuso e as arruelas travando.
- Undo la cordicella, tiri l'alloggio in su e torca sicuro con il bullone e le rondelle di bloccaggio.

12




Slide the grommet down over the coupling to prevent water from entering and complete the assembly.

- Resbale el ojal abajo sobre el acoplador para evitar que el agua entre y para terminar a la asamblea.
- Glissez le canon isolant vers le bas au-dessus de l'accouplement pour empêcher l'eau d'entrer et pour accomplir l'assemblée.
- Schieben Sie die Gummimuffe unten über der Koppelung, um zu verhindern, daß Wasser und die Versammlung durchzuführen hereinkommt.
- Deslize o ilhó para baixo sobre o acoplamento para impedir que a água entre e para terminar o conjunto.
- Faccia scorrere il gommino di protezione giù sopra l'accoppiamento per impedire l'acqua entrare e per completare il complessivo.




Bolt camera to camera bracket as shown.

- Cámara fotográfica del perno al soporte de la cámara fotográfica según lo demostrado.
- Appareil-photo de boulon à la parenthèse d'appareilphoto comme montré.
- Schraubbolzenkamera zum Kamerahaltewinkel, wie aezeiat.
- Câmera do parafuso ao suporte da câmera como mostrado.
- Macchina fotografica del bullone alla staffa della macchina fotografica come indicato.



Loosen the thumb screws to adjust the cameras height and tilt angle.

- Afloje los tornillos de pulgar para ajustar la altura de las cámaras fotográficas y para inclinar ángulo.
- Desserrez les vis de pouce pour ajuster la taille d'appareils-photo et pour incliner l'angle.
- Lösen Sie die Rändelschrauben, um die Kamerahöhe zu justieren und Winkel zu kippen.
- Afrouxe os parafusos de polegar para ajustar a altura das câmeras e para inclinar o ângulo.
- Allenti le viti di pollice per registrare l'altezza delle macchine fotografiche e per inclinare l'angolo.



For 24VAC models connect red and orange (24 VAC wires) to camera power inputs.

- Para 24VAC los modelos conectan rojo y la naranja (24 alambres del VAC) con las entradas de energía de la cámara fotográfica.
- Pour 24VAC les modèles relient rouge et l'orange (24 fils de VCA) aux puissances fournies d'appareil-photo.
- Für 24VAC schließen Modelle Rotes und Orange (24 VAC Leitungen) an Kameraenergie Eingänge an.
- Para 24VAC os modelos conectam vermelhos e a laranja (24 fios do VAC) às entradas de poder da câmera.
- Per 24VAC i modelli collegano rosso e l'arancio (24 legare di VCA) agli input di alimentazione della macchina fotografica.

16								
10	Wire Gauge							
Total vA	,5	,75	1,0	1,5	2,5	4	6	MM ²
consumed	22	20	18	16	14	12	10	AWG
5.5	ft m	400/121	600	960/292	-	•	-	
10	120 36.5	180	300	480	800	1300	-	
20	89 27.1	14143.0	225	358	571	905	1440 438	
30	65 19.8	90 27.4	130 39.6	225	350106	525 160	830	
40	44 13.4	70/21.3	112 34.1	179 54.6	285 86.9	452 138	720/219	
50	35 10.6	56 17.1	90 27.4	14343.6	228 69.5	362 110	576 175	
60	29 9.4	47	75 22.9	119 36.2	190 57.9	91.7	480	L
70	25 8.8	40 12.2	64 19.5	102 31.1	16349.7	258 78.6	411	
80	31 7.6	34 10.3	55 16.8	85 25.9	140	215 65.5	340	L
				1		1		

These are recommended maximum distances for 24VAC with a 10% voltage drop.

- Éstos se recomiendan las distancias máximas para 24VAC con una gota del voltage del 10%.
- Ceux-ci sont recommandés des distances maximum pour 24VAC avec une baisse de volatage de 10%.
- Diese werden maximale Abstände für 24VAC mit einem das 10% volatage Tropfen empfohlen.
- Estes são recomendados distâncias máximas para 24VAC com uma gota do volatage de 10%.
- Questi sono suggeriti distanze massime per 24VAC con una goccia di volatage di 10%.



Fasten down the dome with a Phillips screwdriver.


- Sujete abajo de la bóveda con un destornillador Phillips.
- Attachez en bas du dôme avec un tournevis Phillips.
- Befestigen Sie sich hinunter die Haube mit einem Kreuzkopfschraubenzieher.
- Prenda abaixo a abóbada com uma chave de fenda Phillips.
- Fissisi giù la cupola con un cacciavite "phillips".



Wipe the dome clean.

- Limpie la bóveda limpia.
- Essuyez le dôme.
- Wischen Sie die Haube sauber ab.
- Limpe a abóbada limpa.
- Asciughi la cupola.

FDW8CF2 FDP8CF2 3 4



		art Comments umber		
1	RPFD030	Plastic Housing Top		
2	RP96GK2612	Housing Gasket		
3	WM10	Wall Mount		
4	RP302141	Camera Base Bracket		
5	RPFD080	(12VDC) Blower (for 24VAC Housing)		
6	RPFD100	Trim Ring Assembly for Dome		
7	RCFD8	Clear Replacement Capsule		
7B	RCTFD8	Tinted Replacement Capsule		
8	RP30VL1744	Housing Clamping Bracket		
9	SD0160	Connection PCB		
10	SD0170	24 VAC Heater		
11	RPNET02	Fixed Camera Bracket		
12	RPPKH2094	Pendent Coupling Kit		

Product Registration/Warranty

Thank you for choosing Videolarm. We value your patronage and are solely committed to providing you with only the highest quality products available with unmatched customer service levels that are second-to-none in the security industry.

Should a problem arise, rest assure that Videolarm stands behind its products by offering some of the most impressive warranty plans available: *3 Years* on all Housings, Poles, Power Supplies, and Accessories and *5 Years* on all camera systems (SView, QView, Warriors), and InfraRed Illuminators.

Register Your Products Option 1: Online Option 2: Mail-In

Take a few moments and validate your purchase with our **Online Product Registration Form** at **WWW.Videolarm.com/productregistration.jsp** or complete and mail-in the bottom portion of this flyer.

Register your recent Videolarm purchases and benefit from the following:

- Simple and Trouble-Free RMA process
- Added into customer database to receive product updates / news
- Eliminate the need to archive original purchase documents: Receipts, Purchase Orders, etc...



Cut at the dotted Line

Main Contact Info

Place in envelope, affix stamp and mail to:	Videolarm ATTN: Warranty
	2525 Park Central Ave.
	Decatur, GA 30035

First Name:		Last Name:				
Professional Title:		Company:				
Address 1:		Address 2:				
City:		State / Province/Country:				
ip / Postal Code: Phone Num		nber:	E-mail Address:			
Product Infor	mation	Please Circle One:	Business	Personal		
Name & Location of Compa (City, State, Country)	ny / Store where Pur	chased:				
Videolarm Product ID		Product Description				